REDIRECT I/O 100

HOOK INTERRUPT 13H 102

OBTAIN IMAGE WITH PRE-BOOT CODE 104

READ FILE WITHOUT BOOTED FILE SYSTEM 106

LOAD IMAGE INTO RAM 108

ALLOCATE AND USE EXTENDED MEMORY 110

READ FROM RAM (REDIRECTED I/O) 112

CHANGE BOOT.INI DEFAULT 114

CHANGE FILE NAME FOR NT BOOT RECORD TO LOAD 116

SUBSTITUTE FOR STANDARD NT LOADER 118

SUBSTITUTE MASTER BOOT RECORD 120

PASS CONTROL TO PRE-BOOT CODE 122

BOOT UNDER DOS WITHOUT A DOS PARTITION OR A DOS FLOPPY DISK 124

FLASH (INSTALL) BIOS 126

INSTALL LOGGER FOR BOOT PROCESS DEBUGGING 128

Fig. 1

COMPUTER 200

PROCESSOR 202

RANDOM ACCESS
MEMORY 204

PRE-BOOT CODE LOADING
MEANS FOR READING PRE-
BOOT CODE FROM FILE(S) AND
PASSING CONTROL TO IT 230

PERIPHERAL STORAGE DEVICES 206

FLOPPY DRIVE 208

TAPE DRIVE 212

CD-ROM DRIVE 210

REMOVABLE DRIVE 234

HARD DRIVE 214

MASTER BOOT RECORD 228

PARTITION 216

FILE SYSTEM 218

FILE(S) 220 CONTAINING IMAGE 222
WHICH HOLDS AT LEAST SOME
PRE-BOOT CODE 224

ROM/BIOS 232

USUAL OPERATING SYSTEM(S) 226

Fig. 2